

SINGLE USE GLOVE, 100% NITRILE, POWDER FREE, 240MM LONG, 0.10MM THICK

High performance, powder-free, nitrile single use examination glove. Significantly stronger alternative to latex, dual certified (Industrial and Medical) and food safe.

FEATURES

- › High quality nitrile, soft and durable
- › Palm thickness 0.10mm (4 mil), weight: 5g size M
- › High resistance to penetration and projections of many chemicals
- › Textured finish on fingertips for improved grip and touch
- › Powder-free, latex free, non-sterile, AQL 1.5
- › Chlorinated inside to offer more comfort and reduce friction when donning
- › Antistatic properties due to inherent antistatic properties of nitrile
- › Approved for food handling
- › Dual labelling: PPE and medical
- › Medical device compliant (MDD 93/42/EEC), conforms to EN455 (all parts). Tested against chemotherapy drugs according to ASTM D6978-05. Compliant with ASTM D6319-2019 and ASTM D5151-2019



SUITABLE FOR

Typical Industries

- Aerospace
- Chemical
- Electronics
- Food
- Pharmaceutical
- Manufacturing
- Oil and Gas

Suitable Applications

- Chemical Handling
- Food Handling
- Handling Oily Components
- Laboratory Analysis
- Light Assembly
- Paint Spraying
- Examination

CERTIFICATION



See overleaf for explanation

**PRODUCTION INFORMATION**

MATERIALS	LINER:	Nitrile
	COATING:	–
COLOUR	Blue	
LENGTH (mm)	240	
CUFF STYLE	Beaded	

ORDERING DETAILS

SIZE	CODE	PACKAGING
6/XS	SKG00424DB	100 singles per box (90 singles on size XXL)
7/S	SKG00424DD	
8/M	SKG00424DF	
9/L	SKG00424DH	
10/XL	SKG00424DJ	
11/XXL	SKG00424DL	10 boxes per case

RECOMMENDATIONS FOR USE

- **USE:** Single use glove. Not suitable for mechanical, thermal, heat, electrical, heavy chemical protection. Do not use near moving machines if there is a risk of entanglement
- **STORAGE:** Store in dry conditions in the original packaging and away from direct sunlight
- **CLEANING:** To clean, wipe with a damp cloth. Note: The performance characteristics of worn and laundered gloves may differ from the results shown. Inspect the gloves to ensure no damage is present.
- **LIFETIME:** Service life depends on the glove application and therefore cannot be specified. It is the responsibility of user to ensure the glove is suitable for its intended use

CERTIFICATION LEGENDS

PROTECTION AGAINST
MICRO-ORGANISMS EN 374-5

VIRUS = Glove has passed ISO 16604:2004 (method B)



FOOD CONTACT
DIRECTIVE 2002 / 72 EC



RESISTANCE TO CHEMICAL PERMEATION - EN ISO 374:2016

CODE	CHEMICAL	CODE	CHEMICAL	TYPE OF GLOVES	BREAKTHROUGH TIME
A	Methanol	J	n-Heptane	A	≥30 min for at least 6 chemicals
B	Acetone	K	Sodium hydroxide 40%		
C	Acetonitrile	L	Sulphuric acid 96%		
D	Dichloromethane	M	65% Nitric acid	B	≥30 min for at least 3 chemicals
E	Carbon Disulfide	N	99% Acetic acid		
F	Toluene	O	25% Ammonium hydroxide	C	≥10 min for at least 1 chemical
G	Diethylamine	P	30% Hydrogen peroxide		
H	Tetrahydrofuran	S	40% Hydrofluoric acid		
I	Ethyl acetate	T	37% Formaldehyde		

GLOBUS**EUROPE**

www.globusgroup.com

E: sales@globus.co.uk

T: +44 (0)161 877 4747

F: +44 (0)161 877 4746

MIDDLE EAST & AFRICA

www.globusgroup.com/gcc

E: gcc@globusgroup.com

T: +971 4 882 9962

F: +971 4 882 9963

GLOBUS AMERICAS

www.globusgroup.com

E: americas@globusgroup.com

Globus Group, T2 Trafford Point, Twining Road, Trafford Park, Manchester, M17 1SH, UNITED KINGDOM
 Globus EMEA FZE, Jafza One, Tower A, Office 2201, Jebel Ali, PO Box 61195, Dubai, UNITED ARAB EMIRATES
 Globus Americas LLC, 45 Rockefeller Plaza, Suite 2000, New York City, New York, 10111, USA

EU Type-Examination Certificate issued by SATRA Technology Europe Limited, Bracetown Business Park, Clonee, D15N2P, Republic of Ireland. (Notified Body No. 2777)