

# M9700 SPORTS™

BLACK AND RED FRAME - CLEAR HC LENS

**TECHNICAL  
SPECIFICATION**

SOFT FLEXIBLE NOSE PAD AND RUBBER TEMPLE TIPS ENSURE COMFORT FIT WHILST DUAL CURVED LENS PROVIDE UNCOMPROMISED WIDE VISION AND PROTECTION

**MARTCARE® RANGE**

## INSTRUCTIONS FOR USE

In use ensure that the safety spectacles fit comfortably and securely on the head

Ensure that the safety spectacles are in place, before entering the hazard area

## PERFORMANCE

Lens offers protection against low energy high speed particles at 45m/s (101mph)

The optical qualities of the lens comply with the requirements of optical class 1 (highest)



## DIMENSIONS OF INNER & OUTER PACKAGING

### Inner -

Height: 100mm Width: 160mm Length: 260mm Weight: 493g

Quantity: 10

### Outer -

Height: 440mm Width: 800mm Length: 275mm Weight: 10kg

Quantity: 200

## MATERIALS

Frame: Polycarbonate

Temple: Polycarbonate

Lens: Polycarbonate

Tips: Hard Rubber

Screw: Stainless Steel

Nose Pad: Rubber

## CONFORMITY & MARKINGS

Conforms to EN 166: 2001

### Markings -

Frame: EN 166: 2001-F

Lens: 1.F

## LIMITATIONS OF USE

Protection will only be offered if the safety spectacles are fitted correctly with lenses being inserted correctly

If the safety spectacles become scratched or damaged they should be replaced, likewise if the safety spectacles are subjected to severe impact they should be replaced immediately

Do not apply paint, solvents, adhesives or self-adhesive labels, except in accordance with instructions from the manufacturer

The safety spectacles, when in contact with the skin may cause allergic reactions to susceptible individuals

If this occurs leave the hazard area, remove the eye shield and seek medical advice

The attention of users is also drawn to the dangers of modifying or removing any of the original component parts, other than as recommended by the manufacturer

These safety spectacles are not suitable for protection against dusts, liquids or molten metals

## CLEANING & MAINTENANCE

The safety spectacles may be cleaned with soap and warm water and dried with a soft cloth

Do not clean with chemical or abrasive cleaners

The eye shield should be stored out of direct sunlight, away from chemicals and not exposed to extremes of temperature